



10





(IT) CALZARE LA GUARNIZIONE
 (GB) REMOVE THE GASKET
 (E) QUITAR LA MOLDURA
 (D) DICHTUNG HERAUSZIEHEN
 (F) ÔTER LA JOINT
 (NL) PAKKUNG LOSMAKEN
 (P) RETIRAR A GUARNIZIÃO
 (H) KIHAJTANI A T MIT GUMIT
 (PL) WYCIGNAC USZCZELKE
 (SLO) ODMKNITI TESNILO
 (HR) SKINUTI BRTOVE



SUZUKI LIANA (01->12)
SUZUKI SX4 (06->13)
SUZUKI VITARA (15->)
TOYOTA RAV4 (94->05)

11



(IT) AVVITARE
 (GB) TO SCREW
 (E) APRETAR
 (D) FESTSCHRAUBEN
 (F) VISSER
 (NL) VASTSCHROEVEN
 (P) APERTAR
 (H) MEGH ZNI
 (PL) WKRECIĆ
 (SLO) PRIVITI
 (HR) PRIVRSTITI



5 Nm

